

# INSTALLATION INSTRUCTIONS

1. TIGHTEN PLUG INTO 3/8" PIPE THREAD OPENING.
2. PLACE PACKING NUT ON BULB AND SLIDE NUT UP CAPILLARY.
3. INSERT BULB THROUGH PLUG AND POSITION AS REQUIRED.
4. MOUNT 3 SLOTTED WASHERS ON CAPILLARY, ALTERNATING SLOT DIRECTION.
5. WIND GRAPHITE PACKING AROUND CAPILLARY.
6. PLACE REMAINING 3 SLOTTED WASHERS ON CAPILLARY IN SAME MANNER, AND TIGHTEN PACKING NUT INTO PLUG TO COMPRESS WASHERS AND CENTER PACKING.



CONTROLS COMPANY  
Uni-Line Division  
402 South Temescal Street, P.O. Box 2000  
Corona, CA 91718-2000  
**The Energy Control Company®**

LITHO IN U.S.A. 6/88

1-486